




This camera blocker is perfect for protecting your digital life from hackers spying on you and avoiding scratches on the camera. To install the product correctly first clean the surface where you want to stick this item. Peel off the papers, attach it and press firmly for 5 seconds. Slide over to block/unblock camera. Does not prevent laptops from closing correctly. Compatible with most electronic devices with camera.

Colour



This item in another colour? Go to igopromo.co.uk

Features Brand: Unbranded Dishwasher proof No Minimum quantity: 250 Unit(s) Material: abs Length: 4.10 cm. Width: 1.50 cm. Weight: 0.75 g.

Do you have a specific question or do you want more information about this item, please call 0800 43 46 98 9