



Colour



Width: 1.20 cm. Height: 0.20 cm.

Weight: 0.30 g.

Dishwasher proof No

Provides protection against hackers potentially spying on you, as well as preventing scratches on the camera. Once aligned over the webcam, it needs to be pressed firmly for a few seconds for a strong seal. Then the camera can be blocked/unblocked by sliding the flap to the side. Due to its thin design it does not prevent laptops from closing perfectly. Compatible with most electronic devices with camera.

> Do you have a specific question or do you want more information about this item, please call 0800 43 46 98 9